


ShipSurveyor

Quick Operation Guide



BUTTON PRESS	OFF	NORMAL OPERATION	VIEWING MAX / MIN	GAS ALARM ACTIVE	FLOW FAULT ALARM	ZERO FAULT ALARM	IN 'LOC' LIST
PRESS ▾ (1)		Change Range LEL to VOL (CGI mode)					UP One Item
PRESS & HOLD ▾ (1)	Switch On (CGI mode)	Store Values Switch Off	Clear MIN/MAX	Store Values			Ramp UP
PRESS ▾ (X)		View MAX	View MIN (if available)				DOWN One Item
PRESS & HOLD ▾ (X)	Switch On (CSM mode)	Pump ON/OFF (CGI mode) ZERO (CGI mode)	Return to LIVE Readings	Acknowledge Latching Alarm (CSM mode) Mute Non-Latching Alarm (CSM mode)	Acknowledge Alarm - Switch Pump Back ON (CGI mode)	Acknowledge Alarm	Ramp DOWN
PRESS & HOLD BOTH		Enter LOC List		▾ = Press & Extended Hold			Select & Exit

